## 12VDC 4 WAY 4NO+4NC CONTROL




## AC85V~265VAC 4WAY 4NC+4NO CONTROL




## Size:




## Size:

## Delete the code before study

Press the KEY for 5 seconds until the green light off,it means the code be cleared.

## Learn Momentary Mode

① After delete the code, press the KEY 1 time, the green LED will bright

② Then press the "A" ,the green LED flicker, complete!

## Learn Self Locking Mode

① Press the KEY,wait the green LED off,immediately,green LED flicker once and then twice, release the KEY.

② Press the KEY one time, the green LED will bright,press the "A" ,the green LED flicker, complete!

## Learn Interlocked Mode

① Press the KEY,wait the green LED off,immediately,green LED flicker once and twice then 3 times, release the KEY.

② Press the KEY one time, the green LED will bright,press the "A" ,the green LED flicker, complete!

12V



24V

## The Description